

Fastener Spacing Schedule

| Туре | Panel Size | Test No. | Joist | Span⁴ | Fasteners | Field Spacing ² | Perimeter | Adhesive ^{1,3} | Grout | ULT/LF | DSN/LF |
|-----------|-----------------|----------|-------|-------|----------------------|----------------------------|----------------------|-------------------------|-------|--------|--------|
| T-V Plank | 9" x 47" x 144" | 15-109 | Wood | 144" | 11" 14 Gauge Sip Scr | 7/Joist/Panel | 6" o.c. sides + ends | T & G + Joist + Spline | None | 1251 | 417 |

Notes: 1. Adhesives must meet the requirements of AFG-01. A 3/8" bead of adhesive is to be used. Approximately 38 linear feet of adhesive per quart tube. Specific adhesive used on test assemblies was Degabond Adhesive 948.

Contact Armstrong® Techline for test report data—techline@armstrongceilings.com

1 877 ARMSTRONG armstrongbuildingsolutions.com/tectum

BPRD-1027-1117

All trademarks used herein are the property of AWI Licensing LLC and/or its affiliates

© 2017 AWI Licensing LLC • Printed in the United States of America



^{2.} Values over wood joists are conservative when sup'ports are steel.